

You're going to unplug the **Green**, **Blue**, and **Brown** wires. From here you'll push the two sides in and pop the switch out. Keep the **Yellow** and **Orange** wires intact.

