


Testing with paper

For the Ioline 300/350HF cutter


① What you will need.

- a. Tape.
- b. Piece of paper.
- c. Pen or Pencil




② Taping the paper.

Tape the piece of paper to the tray as shown. Put it in the bottom right corner where the carriage will go after the machine first initializes.



③ Installing the pen.

Install the pen into the carriage as you would the blade holder. Use two pennies to set the height. Set the pen on them and tighten the thumbscrew. Once you remove the pennies you should have a good height for the pen.



④ Plot the Ioline logo

Set the origin where you want to plot then hit the start/stop button to give the machine a red light. HOLD down the “test cut” key for 3 seconds to plot the Ioline logo.

